

SMT118

User Manual



Certificate Number FM 55022

Revision History

Date	Comments	Engineer	Version
22/7/03	First release	GP	1.0

Table of Contents

Revision History	2
Table of Contents	
Block Diagram	4
Power Supply	5
TIM sites	6
JTAG	6
Global Bus	6
CPU	6
I/O	6
Comm-ports	7
Reset	7
Flash	
TTL	
QUART	9
Interrupts	10
Memory Map	12
Board Size	12
Connector Pin-Outs	13
CONN2 - DAC	13
CONN8 - RESET	13
CONN3 – TTL I/O	14
CONN4-7 – RS232	14
CONN9 - JTAG	15
Connector Position	16
How To	17
Write to flash	17
Read / Write to RS232	18
Safety	20
EMC	
Physical Properties	20

Block Diagram



From the block diagram it can be seen that this is a three slot TIM carrier with a CPU site, two I/O sites and various types of I/O.

Each of the sections will be described in detail below.

Power Supply

Power is supplied to the SMT118 via the 4 pin connector HDR9 (referring to connector position section, HDR9 is located at the top right of the drawing). A minimum current of 200mA is required by the circuitry of the SMT118. The maximum current will be dependent on other TIMs mounted on the SMT118.

The on-board supplies are generated by custom designed industry standard pincompatible 2" x 1" DC-DC converters. The 12V module is based around the <u>Micrel</u> <u>2186</u> device and includes an input voltage regulator to allow a maximum of an 18V input. The 5 and 3.3V supplies are based around the <u>Micrel 2182</u> device and these allow an input range from Vout+1.5 to 30V. The individual supplies are rated as follows:

Voltage rail	Minimum input	Max current delivery	
(Volts)	(Volts)	(Amps)	
3.3	4.5	5	
5.0	6.5	5	
12.0	7.0	1	

These values imply a minimum board supply of 7.0V. The maximum input is 18.0V.

Note that a -12V supply is not provided as standard, but an option is available to use a dual output 12 or 15 volt DC-DC converter which will be able to supply both positive and negative supplies to the TIM sites. When this option is installed the board supply voltage must be greater than 10V.

Individual LEDs are illuminated when each of the DC-DC converters becomes active.

TIM sites

The SMT118 has three TIM sites. Only the primary or CPU site can be considered to be 100% TIM standard compliant. The two I/O sites are compliant with the exception of the optional global bus connector.

JTAG

The JTAG chain includes all three TIM sites with the proviso that there must always be a CPU module in SITE 1.

A standard 14-pin XDS510 compatible header (CONN9) is provided to allow debugging.

In addition to the TI standard 14-pin JTAG header, there is a 20 way 0.050" pitch high-density connector which allows direct JTAG connection to the <u>SMT310</u> series of PCI TIM motherboards with embedded test bus controller.

Global Bus

The global bus connectors are essentially all wired in a common bus. This includes the control signals, address and data buses. With this connectivity on the control signals, it is evident that only the CPU site is able to generate global bus 'master' cycles. The two I/O sites are termed 'slaves', and they can contain memory mapped resources which respond to the CPU global bus cycles.

It is not possible to insert a CPU TIM into the I/O sites unless the CPU TIM does not have the optional global bus connector or, that the SMT118 has been specifically modified at build time to remove these global bus connectors from the I/O sites.

CPU

The CPU TIM site connects the global bus address, data and control signals directly to the other I/O sites' global bus connectors.

These signals are also connected to an FPGA on the carrier board which is used to provide the main features of this board.

Interrupts are provided via the FPGA onto the TIM IIOF and NMI signals. These signals are inputs only to the CPU site.

I/O

The I/O sites receive the global bus address bus and control signals. They cannot initiate a global bus cycle independently.

The four interrupt sources from each of these modules are routed to the FPGA (a total of 8 separate interrupts).

Each I/O site has separate connectors to allow serial communication between one another, and also to allow communication to a latching connector on the carrier board. This provision was specifically designed for the SMT366 module and allows the sharing of sampling clocks and outputting of DAC analog signals. There is no

additional electronic circuitry associated with these signals, so they could be used for any general purpose requirement.

Comm-ports

Full Comm-port connectivity is provided using the following scheme:



With this method, a dual pipe exists between the modules in a 0-3 and 1-4 routing fashion. Taking the global bus issues into consideration, three CPU TIMs could be mounted on the SMT118 and good Comm-port communications established.

No active or passive electronic circuitry is connected to these Comm-ports but in normal operating conditions no signal is left un-driven for any length of time.

Reset

As the SMT118 is intended for stand-alone operation, then the system reset must be provided locally. This is implemented by a device which monitors the 5V power line and generates a system reset to all TIM sites and on-board peripherals for approximately $\frac{1}{2}$ second after the power line is stable.

In addition to this reset mechanism there is a reset push-button switch provided, and the shorting of the reset pin to ground (see CONN8 in connector section) will also cause a $\frac{1}{2}$ second reset.

Flash

A 16M bit flash memory is provided and can be accessed through the FPGA. This device can be accessed in either 8-bit or 32-bit mode determined by the setting of a control register. When accessed as a 32-bit word, 15 wait states should be inserted. These wait states are determined by the CPU TIM. For operation with a 'C4x TIM, only 7 wait states need be inserted. For the setting of wait states please consult the respective documentation for the CPU module being used.

The flash memory global address is fixed at 0xF8000000. These addresses, as are all global addresses, are for 32-bit data. If the flash is set to word mode then all 32 bits of data are valid. If set to byte mode then only the lower 8 bits of the data word will contain valid data.

The control register for changing the flash mode is provided at address 0xFC000000. Setting bit 0 of this register will enable word mode.

The flash device cannot be written to when in word mode.

TTL

Twenty-four TTL I/O signals are available via the CONN3 connector. Each signal can be set as either an input or output independently of any other signal. The direction of these signals is controlled by the TTL direction control register at address 0xFA800000. Each of the 24 least significant bits within this register is associated with the direction of the corresponding TTL I/O signal. Setting a bit to logic 1 will enable that I/O as an output. After a reset, all I/O direction is set to input.

These signals are at LVTTL signal levels. They will drive a normal TTL input (V out min of 2.4V), although the use of LVTTL inputs is suggested, they can withstand a 5V input (an absolute maximum of 5.5V and minimum of -0.5V must be ensured).

The output state is controlled by writing to the register at address 0xFA000000, and the input state is determined by reading from this register.

The TTL section of the FPGA can provide an interrupt source when any of the inputs changes state. These inputs are sampled using a 60MHz clock, and so for a change to be recognised, the new state must last longer than 15ns. This input change status bit is cleared when the TTL data register is read (address 0xFA000000).

LEDs

Four LEDs are provided on the SMT118. These can be illuminated under application control by writing to the register at address 0xFB000000. Bits 0 to 3 of this register correspond to the on-board LEDs. Setting a bit to a logic 1 will illuminate the LED.

Another 4 off-board LED signals are provided. These are available on the CONN8 connector. Each of the four bits is controlled directly by the state of bits 4 to 7 of the above register. Setting a bit to logic 1 will output a high LVTTL signal. i.e. if they are intended to drive LEDs, then these outputs should be wired via a suitable (2200hm min) series resistor, to the anode of the LED. The LED's cathode should then be connected to ground.

QUART

The quad UART employed is an Oxford Semiconductor 16C954. It generates TXD, RTS and DTR. It receives RXD, CTS, DSR, DCD and RI. All of these connections are translated to true RS-232 levels and then connected to 10 pin IDC headers (CONN4 to 7) for direct connection of a standard PC pin-out 9-way D-type connector.

The UARTs within this device occupy 8 registers addresses. The base address for the QUART is 0xF9000000, this being the base address for UART1 also. Subsequent base addresses for the UARTs 2, 3 and 4 are 0xF9000008, 0xF9000010 and 0xF9000018 respectively.

The single QUART interrupt is connected to the FPGA and can be used to generate a CPU interrupt.

Interrupts

Each of the four possible interrupt signal inputs to the CPU TIM (IIOF0-2 & NMI) can be configured to generate an interrupt on any combination of the following sources:

I/O site 1 IIOF0-2, I/O site 1 NMI, I/O site 2 IIOF0-2, I/O site 2 NMI, QUART or TTL input change.

Each of the CPU's interrupt input signals has an independent interrupt control register (ICR). These are accessed at addresses 0xFD000000 to 0xFD000003. The following table shows the bit positions to set to enable the various sources:

Bit	Interrupt source
0	SITE 1 IIOF0
1	SITE 1 IIOF1
2	SITE 1 IIOF2
3	SITE 1 NMI
4	SITE 2 IIOF0
5	SITE 2 IIOF1
6	SITE 2 IIOF2
7	SITE 2 NMI
8	QUART IRQ
9	TTL input change

Setting the corresponding bit(s) will enable that interrupt source.

The state of all possible interrupt sources can be determined by reading the interrupt status register (ISR) at address 0xFF000000.

The bit definitions are shown here:

Bit	Function		
0	CPU, IIOF 0		
1	CPU, IIOF 1		
2	CPU, IIOF 2		
3	CPU, NMI		
4	I/O Site 1, IIOF 0		
5	I/O Site 1, IIOF 1		
6	I/O Site 1, IIOF 2		
7	I/O Site 1, NMI		
8	I/O Site 2, IIOF 0		
9	I/O Site 2, IIOF 1		
10	I/O Site 2, IIOF 2		
11	I/O Site 2, NMI		
12	UART RXRDY		
13	UART TXRDY		
14	User link 0		
15	User link 1		

All bits are active low.

Memory Map

Address	Resource	Comment		
(hex)				
F8000000	Flash	Can be ad	ccessed as 8 or 32-bit words. See CSR.	
F9000000	QUART	UART1	F9000000 - F9000007	
		UART2	F9000008 - F900000F	
		UART3	F9000010 - F9000017	
		UART4	F9000018 - F900001F	
FA000000	TTL I/O	Control FA800000 (0=input, 1=output)		
		Data FA000000		
FB000000	LEDs	Data bits 0-3 set to illuminate respective LED.		
		Data bits 4-7 correspond to the off-board LEDs.		
FC000000	CSR	Bit 0 clear to select 8-bit flash mode.		
		Bit 0 set to select 32-bit flash mode.		
FD000000	ICR	Interrupt control register. See interrupt section.		
FF000000	ISR	Interrupt status register. See interrupt section.		

Board Size

The physical size of the board is 145mm x 210mm.

Using a standard IDC connector (with strain relief) inserted onto the SMT366, which is then mounted onto the SMT118, will produce a component height of 24mm above the top surface of the board.

Connector Pin-Outs

CONN2 - DAC

Function	Pin	Pin	Function
DAC 0 out	1	2	GND
	3	4	
DAC 1 out	5	6	GND
	7	8	
	9	10	

CONN8 - RESET

Function	Pin	Pin	Function
RESET IN	1	2	GND
	3	4	CPU BOOT MODE
3.3V	5	6	GND
LED 4	7	8	LED 5
LED 6	9	10	LED 7

CONN3 – TTL I/O

Function	Pin	Pin	Function
TTL I/O 0	1	2	TTL I/O 1
TTL I/O 2	3	4	TTL I/O 3
TTL I/O 4	5	6	TTL I/O 5
TTL I/O 6	7	8	TTL I/O 7
GND	9	10	TTL I/O 8
TTL I/O 9	11	12	TTL I/O 10
TTL I/O 11	13	14	TTL I/O 12
TTL I/O 13	15	16	TTL I/O 14
TTL I/O 15	17	18	TTL I/O 16
GND	19	20	TTL I/O 17
TTL I/O 18	21	22	TTL I/O 19
TTL I/O 20	23	24	TTL I/O 21
TTL I/O 22	25	26	TTL I/O 23

CONN4-7 - RS232

Function	Pin	Pin	Function
DCD	1	6	DSR
RX	2	7	RTS
ТХ	3	8	CTS
DTR	4	9	RI
GND	5	10	N/C

CONN9 - JTAG

Function	Pin	Pin	Function
TMS	1	2	TRST
TDI	3	4	GND
PD(+5V)	5	6	KEY
TDO	7	8	GND
TCK_RET	9	10	GND
ТСК	11	12	GND
EMU0	13	14	EMU1

Connector Position





How To

This section is intended to provide code segments showing the operation of some of the SMT118's features. All of the code has been written for the SMT3x5 TIM, but could easily be recompiled for another module.

In these examples, two functions, <code>read_global</code> and <code>write_global</code> are used to access resources on the global bus. The parameters required are a 32 bit address and optionally the data word.

Write to flash

The flash device fitted on the SMT118 has a write protect mechanism. This flash device supports many different operations, and it is suggested that the data sheet be read for full information. The part number is Am29LV160B.

#define	flash	0xF8000000
#define	flash1	0xf8000AAA
#define	flash2	0xF8000555

In this function, the flash must be set to byte mode and the addr parameter is an offset from the start of the flash.

```
write_flash(unsigned int addr, unsigned int data)
{
    write_global(flash1, 0xAA);
    write_global(flash2, 0x55);
    write_global(flash1, 0xA0);
    write_global(flash+addr, data);
    while((read_global(flash+addr) & 0xFF) != (data & 0xFF));
}
```

Read / Write to RS232

The following functions give an easy interface to the RS232 channels when configured for simple Tx/Rx operation.

The following function is the basic UART register read routine. Supply the UART number (0 to 3) and the register number (0 to 7).

```
#define uart_base 0xF9000000
int read_uart(int uart, int uart_reg)
{
    int data;
    data = read_global(uart_base + uart*8 + uart_reg);
    return(data);
}
```

The following function is the basic UART register write routine. Supply the UART number (0 to 3), the register number (0 to 7) and the required data.

```
write_uart(int uart, int uart_reg, int data)
{
    write_global(uart_base + uart*8 + uart_reg, data);
}
```

The following function is the basic UART receive data routine. Supply the UART number (0 to 3).

```
int rx_uart(int uart)
{
    volatile int t;
// Wait for bit 0 of the UART status register to become set
// indicating that there is data in the receive FIFO.
    while( ( (t=read_uart(uart, 5)) & 0x01) == 0 );
    return(read_uart(uart, 0));
}
```

The following function is the basic UART transmit data routine. Supply the UART number (0 to 3) and the data.

```
tx_uart(int uart, int data)
{
    // Wait for bit 6 of the UART status register to become set
    // indicating that there is an empty space in the transmit
    // FIFO.
    while( ((read_uart(uart, 5)) & 0x40) == 0 );
    write_uart(uart, 0, data);
}
```

The following function shows how to initialise the UARTs for operation at 9600 baud. The divisor is calculated as follows:

divisor = 1.8432e6 / (16 * baud rate)

The 1.8432MHz external clock is supplied by a crystal oscillator, and is such that most standard baud rates can be produced exactly.

```
// Repeat process for all UART channels.
for(u=0;u!=4;u++) {
// Select the UART divisor register.
    write_uart(u, 3, 0x83);
// Set divisor to 0x000C (12).
    write_uart(u, 0, 0x0C); // least significant byte
    write_uart(u, 1, 0x00); // most significant byte
// Select the normal UART registers.
    write_uart(u, 3, 0x03);
}
```

Safety

This module presents no hazard to the user.

EMC

This module is designed to operate from within an enclosed host system, which is build to provide EMC shielding. Operation within the EU EMC guidelines is not guaranteed unless it is installed within an adequate host system.

This module is protected from damage by fast voltage transients originating from outside the host system which may be introduced through the output cables.

Short circuiting any output to ground does not cause the host PC system to lock up or reboot.

Physical Properties

Dimensions	211 x 145 mm
Weight	250g approx. (without TIMs).
Supply Voltage	+7 to 18V
Supply Current	Depends upon installed TIMs. See Power Supply section.
MTBF	