

# SMT317

## User Manual



Certificate Number FM 55022

## Revision History

Date	Comments	Engineer	Version
20/03/01	First Issue	MM	1.0
10/09/01	Minor changes	SS	2.0
16/11/01	Major changes	E.P	3.0
28/11/01	Reduction to Comm-port 3 only for ADC control Comm-port.	E.P	3.1
13/12/01	SMT317v2: <ul style="list-style-type: none"> <li>• Xilinx XCV300 Virtex FPGA only</li> <li>• Addition of a internal trigger</li> <li>• Addition of features in the ADC control</li> </ul>	E.A	4.0
21/02/02	Addition of Bookmarks and hyperlinks Changes in the control word	E.A	4.1
28/02/02	Explanation of the trigger signal Overflowed FIFOs	E.A	4.2
21/04/02	Addition of paragraph 11.x Up dates related to the firmware v2.2	E.A	5
08/07/02	Paragraph 14.2: jumper position correction Explanation of the output frequency on the SDB	E.A.	5.1
29/11/02	Minor changes	E.A.	5.2
01/09/05	Data packeting detailed. Addition of 1 extra bit in control register for burst size. Remove of 100 MHz SDB clock option. New SMT6500 support	E.P	6.0
24/01/06	Minor changes	SM	6.1

## Table of Contents

Revision History.....	2
Table of Contents .....	3
Table of figures.....	4
Table of tables .....	4
Overview.....	5
1. EMC.....	6
2. Power.....	6
3. Notational convention .....	6
4. Outline Description.....	7
5. Power up sequence .....	8
6. ADC Sub-System.....	8
6.1. Input Level .....	8
6.2. Output Codes.....	8
7. Communication ports.....	9
7.1. Overview.....	9
8. SDB .....	10
9. Data formatting .....	10
10. Clock selection .....	11
10.1. ADCs Sampling clock.....	11
10.2. SDB output clock.....	11
10.3. Overflowed FIFOs .....	12
11. FPGA .....	12
11.1. Fpga configuration .....	12
12. ADCs Clock Source.....	12
13. ADC Control .....	13
13.1. Programmable Clock Divider.....	14
13.2. LED 1 .....	14
13.3. Synchronization signal .....	14
13.4. Trigger.....	14
13.5. Control register description .....	15
14. Connectors and Jumpers Positions.....	17

15.	Connectors .....	18
16.	Jumpers .....	19
16.1.	JMP1: Control Comm-port Select.....	19
16.2.	JMP2: SDB Clock speed select and external trigger.....	20
17.	Input Circuitry .....	21
17.1.	SDB Pinout.....	22
18.	Example Code.....	23

## Table of figures

Figure 1: Register Format.....	6
Figure 2: Notational convention .....	6
Figure 3: Block Diagram .....	7
Figure 4: ADCs control register .....	13
Figure 5: SMT317v2 top view .....	17
Figure 6: JUMPER JMPx.....	19
Figure 7: ADC Input circuitry.....	21

## Table of tables

Table 1: Control Register description .....	16
Table 2: Comm-port selection.....	19
Table 3: Clock speed selection.....	20
Table 4: SDB Pinout. ....	22

## Overview

The SMT317v2 is a size 1 TIM offering the following features:

- Communication ports for control
- 8 channels, 16-bit simultaneous sample ADC
- High bandwidth data output via a single 16-bit SDB (Sundance Digital Bus)

## 1. EMC

This module is designed to operate from within an enclosed host system, which is built to provide EMC shielding. Operation within the EU EMC guidelines is not guaranteed unless it is installed within an adequate host system.

This module is protected from damage by fast voltage transients originating from outside the host system, which may be introduced through the output cables.

Short-circuiting any output to ground does not cause the host PC system to lock up or reboot.

## 2. Power

This module must be fixed to a TIM40 compliant carrier board. Additionally, a 3v3 power source must be provided to the fixings. This is normally achieved by means of a power source provided directly through conducting pillars on the carrier board. On-board dc-dc converters provide power for the analog components on this module.

All of the analog circuitry is shielded on the top and bottom of the module using custom RFI shielding cans.

## 3. Notational convention

The format of registers is described using a diagram of the following form:

31–20	19–17	16–8	7–0
	LED[4:2]		
W,000000000000	W,100	W,000000000	W,10000000

Figure 1: Register Format

The digits at the top of the diagram indicate bit positions within the register and the central section names bits or bit fields. The bottom row describes what may be done to the field and its value after reset. Shaded fields are reserved and should only ever be written with zeroes.

<b>R</b>	Readable by the CPU
<b>W</b>	Writeable by the CPU
<b>RW</b>	Readable and writeable by the CPU
Binary digits indicate the value of the field after reset	

Figure 2: Notational convention

## 4. Outline Description

The SMT317v2 module is an ADC-based size 1 TIM offering the following features:

- Eight 16-bits ADCs running at an output word rate of up to 1.2 MHz for input bandwidths up to 460 kHz.
- a Xilinx XCV300 Virtex FPGA.
- FPGA programming via communication port (comm-port3).
- High bandwidth data I/O via 1 Sundance Digital Bus (SDB).




Figure 3: Block Diagram

## 5. Power up sequence

At power up the config CPLD waits for a bitstream to configure the FPGA.

The Virtex FPGA from Xilinx is volatile in nature, and requires reconfiguring every time the module is powered on.

From the moment the module is powered on to the time when the FPGA is configured:

- The ADC sampling clock is the external clock (beware to respect the maximum frequency rating, see [ADC Datasheet AD7723](#))
- The ADC SYNC (See [ADC Datasheet AD7723](#)) signal is maintained high to keep the ADCs in reset state

After the FPGA is configured the ADC controls default to the values in

Table 1: Control Register description.

## 6. ADC Sub-System

It consists of 8 Analog Devices AD7723 converters. These provide an overall system performance with an ENOB of 14 (minimum) for each of the eight channels.

All ADCs simultaneously sample using the same clock.

### 6.1. Input Level

The input to the ADC module is DC coupled with a pk-pk level of 4v. This is centred about 0v.

$$V_{\min} = -2v, V_{\max} = +2v.$$

### 6.2. Output Codes

The converted samples are presented on the SDB connector as 16 bits two's complement binary.

Code 0x8000 is equivalent to  $-V_{\max}$

Code 0x0000 is equivalent to 0V

Code 0x7FFF is equivalent to  $+V_{\max}$



## 7. Communication ports

### 7.1. Overview

The SMT317 communication port is an 8-bit, data-parallel, link that follows Texas Instruments' TMS320C4x Communication Port standard. Additional information on the standard is available in the TMS320C4x User's Guide chapter 12: *Communication ports and the Texas Instrument Module Specification*.

**The standard gives a TIM six links numbered from 0 to 5. Each link can be a transmitter or a receiver, and will switch automatically between these states depending on the way you use it. Writing to a receiver or reading from a transmitter will cause a hardware negotiation (token exchange) that will reverse the state of both ends of the link.**

Following a processor reset, the first three links (0, 1, and 2) initialise as transmitters and the remainder (3, 4, and 5) initialise as receivers. When you wire TIMs together you *must* make sure that you only ever connect links initialising as transmitters to links initialising as receivers; never connect two transmitters or two receivers. For example, connecting link 0 of one TIM to link 4 of another is safe; connecting link 0 of one TIM to link 2 of another could damage the hardware.

**Always connect comm-ports 0, 1, or 2 to comm-ports 3, 4, or 5.**

**On the SMT320-SMT310Q carrier board the physical connection between comm-ports is made with FMS cables. You must be careful when connecting the cables and make sure that one end is inserted in the opposite sense to the other. One end must have the *blue* backing facing out and the other must have the *silver* backing facing out.**

The SMT320 SMT310Q motherboard communicates with the host PC using comm-port 3 of the site 1 TIM. You should not make any other connections to this comm-port.

On the SMT317

- Comm-port 3 is used for the FPGA configuration. It is the only way to configure the FPGA.
- Comm-port 3 is used for both configuring the FPGA and afterwards for controlling the ADCs data acquisition. In that configuration you save one connection in your system.
- Nevertheless, if your application requires using a different Comm-port **to control the acquisition**, (the FPGA configuration can only be done via Comm-port3) please contact Sundance as a custom version of the firmware with more Comm-port connections could be developed for you.
- The control comm-port selection is achieved by setting
- **JMP1: Control Comm-port** Select. The standard version of the firmware only provides Comm-port 3.

## 8. SDB

The SMT317 provides one Sundance Digital Bus (SDB). This 16-bit data parallel link for synchronous transmission can achieve high-speed data transfer across 40-way flat ribbon cables with ground-interlaced 3.3v signals (Ref. SMT3xx-SDB-CAB).

The SDB is connected directly to the Virtex device. The SDB implementation on this module operates as an **output only**.

The user defined pins (UD0, UD1) are not used. The write enable pin (WEN) is driven active (low) by the SMT317 when it is transmitting data on the SDB. The SDB drives at LVTTTL levels. The SDB pinout is described in

### **Table 4.**

The SDB interface present in the SMT317 implements a flow control meaning that when the receiver on the other end stops receiving, the data is not overwritten but pills up in the SMT317's own FIFO until it is full. Only then data is overwritten.

The SDB interface provides a 511 position FIFO. Each position is 32-bit wide.

The 16-bit SDB interface only transfers multiples of 32-bit words.

Only one transfer speed is available on the SMT317 SDB released after 01/09/2005.

The clock speed is 50 MHz.

You should refer to SDB specifications V2.0 and above for technical information.

## 9. Data formatting

The sampled data is output on the SDB (Sundance Digital Bus) connector.

The physical link presents ADC samples one at a time (16-bit wide) but the SMT317 packets ADC data samples by pairs and sends multiples of 2 x 16-bit packets with the least significant bit being sent on D0.

The channels are paired in the following manner:

Ch0, Ch4,

Ch1, Ch5,

Ch2, Ch6,

Ch3, Ch7.

Enabling a pair of channels is done by setting any one or both of the two control bits corresponding to the 2 channels from that pair in the control register described further down.

Only the data corresponding to the enabled channel pairs will be output on the SDB.

On the start of a new acquisition (in continuous or burst mode) the data from the channel pair selected with the smallest channel number is always output first.

For example, Ch0-Ch4 data is always output before Ch2-Ch6 data. Then samples are output by increasing channel pair number for the selected channel pairs.

## 10. Clock selection

### 10.1. ADCs Sampling clock

All ADCs are sampled at the same time.

The clock source can either be the onboard oscillator or an external clock.

Therefore, the sampling frequency is either given by the clock divider setting for the onboard clock or by the external clock (the external clock is not affected by the clock divider setting).

### 10.2. SDB output clock

For firmware versions released before 01/09/2005, the SMT317 module allows for the SDB word rate to be set to either 50 or 100MHz as set by **JMP2: SDB Clock speed select**.

A lower word rate may be needed when the receiving device is not able to sustain the faster transfer speed.

In firmware versions released after 01/09/2005, the SDB clock is no more selectable and the samples are output at a default 50Mhz clock frequency, which can easily sustain the data rate required by the ADC data.

If the SDB data transmission is not suspended by the ACK signal and that there are samples buffered in the SMT317 FIFO, the samples are output at the SDB output clock frequency.

### 10.3. Overflowed FIFOs

In the case the receiving device has a FIFO, which is becoming full, the ACK signal on the SDB connector can be used to suspend SDB data transmission, whichever mode is selected (continuous mode or burst mode). As soon as the ACK signal is released the transmission continues.

Indeed when a data is written in a 511x16-bit FIFO this data is immediately read and sent via the SDB to the DSP.

But if the ACK signal on the SDB is active the sampled data are stored in the 511x16-bit FIFO. The data are outputted on the SDB cable as soon as the ACK signal is not active anymore.

If the 511x16-bit FIFO becomes full when the ACK signal is still active the LED1 is lit.

In order to clear the overrun the user has to clear the SDB receiver's FIFO and send a new control word to the SMT317.

## 11. FPGA

A Field Programmable Gate Array (FPGA) is used to manage the ADC data acquisition, implement one communication ports and one Sundance Digital Bus.

### 11.1. Fpga configuration

The Virtex FPGA from Xilinx is volatile in nature, and requires reconfiguring every time the module is powered on. The configuration data (bitstream) must be presented through Comm-port 3.

The bitstream is supplied on the distribution disk as 'fpga\_smt317v2.bit'.

Please refer to the [SMT6500 help file](#) in the section FPGA type TIM configuration for more information.

When the module is not configured, LED5 will be illuminated. Upon successful configuration, LED5 will extinguish. (LED5 located near TIM connector.)

## 12. ADCs Clock Source

The sample rate of the ADCs is derived from one of two sources: either from an external clock input or via the on-board reference.

The on-board reference clock is generated by a 37.6 MHz oscillator. The highest ADC clock frequency generated by the on-board clock is 18.8 MHz, which can be divided up to 16 times. See

Table 1: Control Register description

The maximum external ADC clock frequency is 19.2MHz. This should be TTL compatible.

It is not possible to divide the external clock using the *Programmable Clock Divider*.

The buffered external clock is used directly as the ADCs sample clock.

### 13. ADC Control

All of the ADCs are controlled via the comm-port 3. The comm-port 3 must be selected using the jumper bank

**JMP1: Control Comm-port Select.**

The ADC control is provided by configuring a single control register. It allows control for the clock divider, the clock selection, the trigger source, the mode (), the ADC enable and the state of three LEDs. This register is described here,

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
Count_data_fifo			Trigger_int	Internal trigger	Active trigger level	Continuous mode	Half pwr	Internal Sync	Mode 1	Mode 0	EXT Clock	LED [4:2]			Extra Count_data_fifo bit
W,000			W,0	W,0	W,0	W,0	W,0	W,0	W,0	W,0	W,0	W,000			

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
CH7	CH3	CH6	CH2	CH5	CH1	CH4	CH0	Rst SDB	Not Used			CLK DIV			
W,0	W,0	W,0	W,0	W,0	W,0	W,0	W,0	W,0				W,0000			

Figure 4: ADCs control register

### 13.1. Programmable Clock Divider

A 4-bit divider is provided which allows generating up to 16 different clock frequencies for the ADC clock from the on-board reference clock.

$$\text{ADC Clock Frequency} = 18.8 / (\text{Divider Value} + 1) \text{ (MHz)}$$

Sampling frequency = ADC Clock/16

The programmable divider on default setting is to divide by 16.

The programmable divider has no effect on an external clock.

### 13.2. LED 1

The LED 1 is lit when the 511x16-bit FIFO is full.

In order to clear the overrun the user has to clear the SDB receiver's FIFO and send a new control word to the SMT317.

### 13.3. Synchronization signal

It's a pulse active high.

If the internal synchronization signal is selected (bit23=1) as soon as a control word is received a pulse is generated internally to synchronize all the ADCs.

If the external synchronization signal is selected (bit23=0) the user has to send a pulse active high to the SMT317 via the SYNC connector to make sure all the ADCs are synchronized together.

### 13.4. Trigger

In Continuous mode:

The trigger is a level. As long as the trigger is active the data are sent to the DSP board via the SDB.

The active level is selectable. The trigger can be active high (bit26=1) or active low (bit26=0).

In Burst mode:

The trigger is an edge.

In the case of an internal trigger, every time a new control word is sent with burst mode selected and internal trigger selected then a new burst mode occurs.

In the case of an external trigger, the burst mode occurs as soon as an edge is detected on JP2 of JMP2 (0). The trigger is edge selectable:

- Bit26=1 the burst is triggered on a rising edge.
- Bit26=0 the burst is triggered on a falling edge.

### 13.5. Control register description

The following table describes how behave the different fields of the control register depending on their value.

FIELD	DESCRIPTION	ACTION	DEFAULT
CLK DIV	Clock divider.	ADC Clock Frequency CLKDIV = 0    18.8 Mhz CLKDIV = 1    9.4 Mhz CLKDIV = 2    6.27 Mhz CLKDIV = 3    4.7 Mhz CLKDIV = 15   1.17 Mhz	CLKDIV=15
Rst_SDB	Reset FIFO	Rst_SDB = 1: Clear outgoing SDB FIFO and send a Reset SDB for the receiving end (Reset only valid for SMT332/372).  Can be used to synchronise data at the receiving end	Rst_SDB = 0
CHx	ADC Channel x enable in outgoing SDB FIFO.	CHx = 1 enables ADC channel x CHx = 0 disables ADC channel x	CHx = 1
LEDx	LEDx illumination.	LEDx = 0 lights LEDx LEDx = 1 turns LEDx off	LED[4:2]=101
EXT Clock	Select the sampling Clock source.	EXT = 1 selects external clock EXT = 0 selects internal clock	EXT = 0
MODE 0, MODE 1	Parallel/Serial interface	See <a href="#">ADC Datasheet AD7723</a>	MODE 0 = 0 MODE 1 = 0
Internal SYNC	Synchronisation logic	Internal_SYNC = 1, an internal pulse is sent to SYNC. Internal_SYNC = 0, an external signal is used for SYNC. See <a href="#">ADC Datasheet AD7723</a> about SYNC function.	Internal_SYNC = 0

Half pwr	Half Power	See <a href="#">ADC Datasheet AD7723</a>		Half_pwr = 0
Continuous mode	Continuous mode	Continuous mode = 1 selects the continuous mode		Continuous_mode = 0
		Continuous mode = 0 selects the burst mode		
Active level trigger	Active level trigger	Active_level_trigger = 1, trigger active high or rising edge		Active_level_Trigger = 0
		Active_level_trigger = 0, trigger active low or falling edge		
Internal trigger	Trigger logic	Internal_trigger = 1 selects the internal trigger		Internal_Trigger = 0
		Internal_trigger = 0 selects the external trigger		
Trigger_int	Trigger signal	To drive the internal trigger in continuous mode only (enable signal)		Trigger_int = 1
Count_data_fifo	Number of data to be transferred during a burst operation. Only used in burst mode. Bit16Bit31Bit30Bit29	Count_data_fifo=0000	256 samples	Count_data_fifo[3:0] = 0000
		Count_data_fifo=0001	512 samples	
		Count_data_fifo=0010	1Ksample	
		Count_data_fifo=0011	2Ksamples	
		Count_data_fifo=0100	4Ksamples	
		Count_data_fifo=0101	8Ksamples	
		Count_data_fifo=0110	16Ksamples	
		Etc... up to Count_data_fifo=1111	8Msamples	

Table 1: Control Register description



**Remark:**

The trigger signal is different depending of the mode selected:

- In *burst mode*, the trigger is an edge.
- In *continuous mode*, the trigger is a level.

The user has to make sure he inputs the right external trigger signal according to the mode selected.

## 14. Connectors and Jumpers Positions




Figure 5: SMT317v2 top view

## 15. Connectors

**SYN** connector (bottom right end side of the top view) is for synchronising all ADCs operated from a common master clock. It allows each ADC to simultaneously sample its analog input and update its output register (See [ADC Datasheet AD7723](#)).

**CLOCK** connector (bottom right end side of the top view) is for the external clock.

**CH X** are the analog inputs.

### WARNING!!!

The connector of the channel 7 is very close to the 3.3V. However the ADC female connector is connected to the ground. It's very important to check that the ADC female connector and the 3.3V are not in contact to avoid any short cut, which could damage the system. The best is to have a straight ADC female connector instead of a right-angled connector for this channel.

## 16. Jumpers

**JMP1** is a header located to the left of the JTAG pins,

**JMP2** is a header to the right, closer to the TIM connector.

The Jumpers **JPx** are numbered from the left to the right: JP1, JP2, JP3 for each connector JMPx

JP1, JP2 and JP3 refer to the following link positions on JMPx:




Figure 6: JUMPER JMPx

### 16.1. JMP1: Control Comm-port Select

JP1	JP2	JP3	Comm Port
OUT	OUT	OUT	N/A
OUT	OUT	IN	N/A
OUT	IN	OUT	N/A
OUT	IN	IN	3
IN	OUT	OUT	N/A
IN	OUT	IN	N/A

Table 2: Comm-port selection

## 16.2. JMP2: SDB Clock speed select and external trigger

- SDB Clock speed select:

JP1	JP2	JP3	CLK (MHz)
IN	N/A	N/A	50
OUT	N/A	N/A	100

Table 3: Clock speed selection

- External trigger

JP2 is used to apply the **external trigger** signal.

The trigger signal is different depending of the mode selected:

- In **burst mode**, the trigger is an edge.
- In **continuous mode**, the trigger is a level.

**The user has to make sure he inputs the right external trigger signal according to the mode selected.**

## 17. Input Circuitry

The jumper located near the channel input connector is used to select the input mode.

If the jumper is installed it selects single-ended input.




Figure 7: ADC Input circuitry

## 17.1. SDB Pinout

Function	Pin	Pin	Function
GND	2	1	CLK
GND	4	3	DATA0
GND	6	5	DATA1
GND	8	7	DATA2
GND	10	9	DATA3
GND	12	11	DATA4
GND	14	13	DATA5
GND	16	15	DATA6
GND	18	17	DATA7
GND	20	19	DATA8
GND	22	21	DATA9
GND	24	23	DATA10
GND	26	25	DATA11
GND	28	27	DATA12
GND	30	29	DATA13
GND	32	31	DATA14
GND	34	33	DATA15
GND/DIR	36	35	USERDEF0
REQ	38	37	WEN
ACK	40	39	USERDEF1

**Table 4: SDB Pinout.**

## 18. Example Code

Code to use with a smt335.

Comm-port 1 (SMT335) have to be connected to the Comm-port 3 (SMT317).

The SDB (SMT317) is linked with the SDB B (SMT335).

```
#include <stdio.h>
#include <sema.h>
#include <thread.h>
#include "smt317v2.h"
#include "Fast_FpgaConf.c"
#include "sdb.h"

/***** PROTOTYPES *****/
void fill_internal_b(void *);
void Fast_FpgaConf(int len, unsigned int *b, int link_no);
void *calloc(size_t _num, size_t _size);
/*****/

#define BURST1K_IntClk_IntTrigger_low_IntSync 0X49ea0101

SEMA internal_filled_b;
int *samplestore;

main()
{
//Corresponds to the only bitstream in the Dat2asm.bat file
extern far int fpga_count;
extern far unsigned int fpga_data[];

int control_word;
```

```
//Allocation of a memory space to store the samples
    samplestore=(int*)calloc(BUFFER_SIZE,sizeof(int));

if (samplestore!=NULL & samplestore_slave!=NULL)
    printf("memory allocation was successful\n");
else
    exit(1);

    printf("Address of samplestore:%08x \n",samplestore);

/*****FPGA CONFIGURATION*****/
printf("\nFirst bitstream\n");
    Fast_FpgaConf(fpga_count, fpga_data, COMMPORT1);
printf("\nEND... \n");

/*****ACQUISITION*****/
SDB_init(SDB_CLROF|SDB_CLRIF|SDB_CLK,
        SDB_CLROF|SDB_CLRIF|SDB_CLK);

control_word = BURST1K_IntClk_IntTrigger;
link_out_word(control_word, COMMPORT1);

sema_init(&internal_filled_b, 0);
thread_new(fill_internal_b, 1000, 0);
sema_wait(&internal_filled_b);

printf("done\n");
}

void fill_internal_b(void *x)
{
    SDB_read (BUFFER_SIZE*sizeof(int), samplestore, SDB_B);
    sema_signal(&internal_filled_b);
}
```